


Model:
PRS McCarty TCI Lefty



Note: Pickup shape is just for reference.
All pickups using this diagram shall be oriented in this manner.

Bass (Neck) Pickup

South

North


Treble (Bridge) Pickup

South


North

Bridge location

3-way Pickup Selector Switch:



Push-pull Tone Pot:



Operating Instructions

3-way toggle pickup switch:

- Position 1 (down) - Treble Pickup
- Position 2 - Treble and Bass Pickups
- Position 3 (up) - Bass Pickup

Push-Pull Tone Pot:

- Down - Humbucker Mode
- Up - Single Coil Mode